

MyToys

my toy, my joy!



MyMiniBunny – User Manual

MyMiniBunny is a vibrating bunny egg, with 2 motors and 10 powerful vibration, pulsation and escalation functions. The unique shaped body has a flexible and bendable handle, for easily pulling in and out. Moreover it can be transformed into a wearable vibrator for stimulating the anal zone. The hypoallergenic premium silicone is body safe, unscented and phthalate free to keep your most sensitive spots, happy and healthy.

Features :

- The slim flexible and bendable tail, is versatile to use as handle and can easily be transformed to stimulate the anal zone.
- For solo and partner play
- Two powerful motors
- For clitoris, G spot and anal stimulation
- 10 different vibration modes
- Rechargeable
- Waterproof

How to use

1. Charging

Please fully charge the product for about 120 minutes before first use.





LED flashes : charging

LED lights on: fully charged

Charging port




2. Control

Press and hold the “” button to activate the unit, and then short press the “” button to turn on the motor
Short press the “” button to select a different mode
Long press the “” button to turn it off

3. More pleasure to be discovered

• Solo play



• Play with partner



Specification

- **Material:** fully covered with liquid silicone
- **Power:** 3.7 V / 300 mAh rechargeable battery
- **Size:** 220 x 68 x 33 mm
- **Modes:** 10 vibration patterns
- **Operation time:** 50 minutes
- **Charging time:** 120 minutes
- **Noise:** < 55 db
- **Waterproof:** IPX7

Care and Guarantee

For the most pleasurable sensation, apply some water-based lubricant to your body and to the product before and during use.

Before and after use, please rinse it with water and then spray the “toy cleaner” on the product, 30 seconds later, please wipe it clean and keep it in the box. The product is guaranteed for 1 year from the date of purchase. If you experience problems, please contact the vendor you bought the product from.

MyMiniBunny 是一款擁有兩個強勁馬達的震動跳蛋，產品擁有10種震動模式，花樣探索。與市面上的跳蛋不同的是，它獨特的尾部靈活可彎曲設計，賦予它更多愉悅玩法：可像兔子震動棒一樣進出體內抽插，小巧棒身，輕輕進出。還可以變形成穿戴震動器，小巧尾巴能夠貼合刺激肛門區，體驗三重愉悅快感。產品採用低敏優質硅膠，無異味不含鄰苯二甲酸鹽，對身體無害，可讓您最敏感脆弱部位盡情享受愉悅快感。

特點:

- 靈活、可彎曲定型尾巴設計，可作為震動棒進出體內，也可變形為穿戴跳蛋，刺激肛門
- 2個強勁馬達，強震酥麻刺激
- 用於陰蒂和G點、肛門刺激
- 適用於單人自慰和與伴侶調情遊戲
- 10種震動模式
- USB充電設計
- 全身防水

如何使用:

1. 充電

首次使用請充電120分鐘



LED 燈閃爍: 充電中


LED 燈常亮: 充滿

充電孔



2. 開關機

請長按“”按鍵激活產品，此時LED燈會常亮，然後再短按“”按鍵開啓產品

短按“”按鍵切換不同的模式


長按“”按鍵開機

3. 探索更多玩法


• 自慰玩法1



• 自慰玩法2



• 和伴侶一起探索愉悅



規格:

- 材料:液態全包膠
- 電源: 3.7 V / 300 充電電池
- 尺寸: 220 x 68 x 33 mm
- 模式: 10 種震動模式
- 運行時間: 50 分鐘
- 充電時間: 120 分鐘
- 噪音: < 55db
- 防水: IPX7

護理和質保

為了獲得最愉悅的感覺，請在使用前和使用期間在您的身體和產品上塗抹一些水基潤滑劑。使用前後請用清水沖洗乾淨，然後將“玩具清潔劑”噴灑在產品上，30秒後擦拭乾淨並保存在盒內。產品自購買之日起保修1年。如果您遇到問題，請聯繫您購買產品的供應商。